

Exp. No.: 3	Stacking Operation
Date:	

Aim:

To write a program in RT Toolbox3 for the robot to stack elements at a desired location from a pallet.

Procedure:

- Power On and Initialize the Robot
- Command the robot to move to its designated home position.
- Activate the gripper and ensure it is in the open position.
- Define a picking pallet with 6 elements being picked at (344, -590, z) and program the robot to move to the position (450, 5, z) for the first element and the remaining elements with 40 mm offset.
- Command the gripper to close and securely grasp the first element.
- Specify the desired location for stacking. This may involve stacking cubes in a specific orientation or arrangement.
- Lift and move the first object to the desired stacking location.
- Command the gripper to open and release the first cube, allowing it to stack in the designated order.
- Repeat the sequence until all the objects in the pallet are moved to the stacking location.
- Send the robot back to its home position once the stacking operation is complete.

RT Toolbox3 Program:

--	--

--	--

Observation:

Analyze the stack of the objects ensuring that they are accurately standing at the desired location.

Results & Inference: